



2310 Tice Valley Blvd., Walnut Creek, CA 94595

Bramidan Raising Cylinder Control Steps if misaligned 7/15

Place baler into "manual mode" (where cylinder can be moved up and down manually), by:

- a) press e-stop
- b) press green start button and hold it in
- c) release e-stop while green button is held in
- d) release green button
- e) press green button one more time

The baler should now flash between green and orange light (back and forth)

To get baler into operation mode, push e-stop, release e-stop, push green to reset (green should be lit up without flashing)