

## Summit SV2 Controls / Operation



“**AUTO**” Position allows ram to compact down and return to the top  
“**HOLD**” Position allows ram to compact and stay down. This maximizes compaction by eliminating trash memory and swelling.

### Operation

#### “**AUTO**”

1. Open door noting that ram is up and place trash in chamber
2. Close gate and push **GREEN** Start button
3. Ram will go down and return to top.
4. If ram stays down and **GREEN** button illuminates the compactor is **FULL**.
5. To empty **FULL** machine raise ram by pushing in **RED STOP** button, hold bottom **TOGGLE SWITCH** to **UP**
6. Remove bin, release **RED STOP** button by twisting button. Set bin for pick up, carefully roll empty bin into compactor

#### “**HOLD**”

1. Open door noting that ram is up and place trash in chamber
2. Close gate and push **GREEN** Start button
3. Ram will go down and machine will turn off with ram down.
4. If ram stays down and **GREEN** button illuminates the compactor is **FULL**. If **GREEN** button not illuminated compactor is not **FULL**
5. To raise ram, place **KEY** switch in **AUTO** and push **GREEN** Start. Ram will return to top with gate closed.
6. Reload compactor with more waste, push **GREEN** Start button
7. Once ram stays down AND **GREEN** button illuminates the machine is **FULL**
8. To empty **FULL** machine raise ram by pushing in **RED STOP** button, hold bottom **TOGGLE SWITCH** to **UP**
9. Remove bin, release **RED STOP** button by twisting button. Set bin for pick up, carefully roll empty bin into compactor